

SEATS

APPLICATION

This inspection applies to all vehicles.

When checking the driver's seat adjustment it is not necessary to check that the seat can be secured in all possible positions.

In the case of electrically adjusted seats, it is not necessary to check that any 'memory position' function

PROCEDURE AND STANDARDS

- Check all seats for condition and security of the seat, seat back, cushion and adjusting mechanism.
- Where a seat adjustment mechanism is fitted, check that the driver's seat position can be adjusted forwards and backwards and secured in the selected positions.

REASONS FOR FAILURE

	Deficiency Category
1. A seat, mounting or adjusting mechanism insecure or in such a condition that it could potentially cause injury to an occupant.	MAJOR
2. A seat backrest that cannot be secured in the upright position.	MAJOR
3. A driver's seat, mounting or adjusting mechanism so insecure or in such a condition that it could cause the driver to lose control of the vehicle.	DANGEROUS
4. The driver's seat fore and aft adjustment mechanism not functioning as intended.	MAJOR