

ENGINE AND TRANSMISSION MOUNTINGS

INFORMATION

This inspection applies to all vehicles.

METHOD OF INSPECTION

Note:

'Chassis' includes the underframe on integrally constructed vehicles.

Examine the presence and condition of:

- Mountings
- Subframes

and their security to the chassis and check for:

- Looseness
- Fractures
- Deterioration

REASON FOR REJECTION

	Deficiency Category
1. Any mounting or subframe:-	
a. Missing	MAJOR
b. Fractured,	MAJOR
c. Insecure but unlikely to detach or fail	MINOR
d. Damaged or deteriorated to the extent that it is likely to fail	MAJOR

If a security bracket to stop the engine or transmission falling in their mountings fails or is absent or deteriorated, this is not a reason for rejection, but the driver should be told.